



7.5" Sleeper depth takes into account 6.5" from the exterior framing towards the interior and 1" extending past the exterior framing. The 1" extension is needed to support the outer track. 7.5" sleeper width does not take into account: pans, membranes & sealant provided by others.

Description: 3 Panel - Sleeper Sill Installation	File name: 2300 MultiSlide - Master
Notes: $6\frac{1}{2}'' \times \frac{3}{4}''$ void in concrete	Layout: 23MS-3 Panel Sleeper Sill