



Vertical Section

1" extends past the framing to the exterior

10" Sleeper depth takes into account 9" from the exterior framing towards the interior and 1" extending past the exterior framing. The 1" extension is needed to support the outer track.  
 10" sleeper width does not take into account: pans, membranes & sealant provided by others.



450 Delta Ave  
 Brea, CA 92821  
 (714) 221-8624

Notice: This document contains information proprietary to and is protected by copyright of Win-Dor Inc. and shall not be copied, disclosed to others, or used for any purpose other than that for which it is given, without the written permission of Win-Dor Inc.

Date: 20151006  
 Drawn by: D May

Description: 4 Panel - Sleeper Sill Installation  
 Notes: 10" x 3/4" void in concrete

File name: 2300 MultiSlide - Master  
 Layout: 23MS-4 Panel Sleeper Sill