



1 3/8" extends past the framing to the exterior

10 1/2" Sleeper depth takes into account 9 1/6" from the exterior framing towards the interior and 1 3/8" extending past the exterior framing. The 1 3/8" extension is needed to support the outer track. 10 1/2" sleeper width does not take into account: pans, membranes & sealant provided by others.

450 Delta Ave  
Brea, Ca 92821  
(714) 385-1202



Notice: This document contains information proprietary to and is protected by copyright of Win-Dor Inc. and shall not be copied, disclosed to others, or used for any purpose other than that for which it is given, without the written permission of Win-Dor Inc.

Project:	File name: 3750 4 Panel Multislide Wall Detail - 1.375 inch Nail-fin - .75 inch Sleeper Sill	Date: 20180202
Notes:	Layout: 4 Panel Multislide with .75 inch Sleeper Sill	Drawn by: J Johnson