
This file contains the scalable dynamic block for our 2750 Series 4 Panel Folding Window. Here is how to use them:

- I. Copy the desired block and paste it in your drawing.
- 2. Select the Item and open the Properties tab.
- 3. At the bottom of the Properties tab you will see a Custom section. From there you can change the panel configuration and the width.

4.0.4 Outswing

Exterior

Panels not to scale



╌	Project:	File name: 2750 Folding Door Configuration - 4 Panel	Date: 20180509
	Notes:	Lavout: 4 Panel Configuration	Drawn by: J Johnson